



**FARROW FLOW®
HVLP PAINT &
POWDER COATING INSERT**

FF-1787-P

THE FIRST, THE FASTEST, THE FUTURE

Thank you for your purchase!

The Farrow Flow® insert for HVLP Paint and Powder Coating guns is the only patented insert of its kind designed to spin the air in a vortex pattern inside of your airline before the tip to provide you with a wider paint pattern at the tip saving you time, paint, powder and providing improved transfer efficiency.

We value your trust in our product and welcome your feedback.

30-DAY MONEY BACK GUARANTEE!

Included in this Package:

(a) ONE (1) Farrow Flow Insert for HVLP PAINT & POWDER COATING

(b) TWO (2) Straight Connectors:

- 10MM Push to Connect X 8MM Push to Connect

(b)

(a)

(b)



Installation Instructions

| | |
|----|--|
| 1 | Turn off air supply to paint or powder system. |
| 2 | Disconnect air line at the regulator. |
| 3. | Make one clean straight cut in the air hose leading to the gun. |
| 4. | Insert the Farrow Flow assembly by gently pushing the hose into the straight connectors. |
| 5. | Reconnect air supply to paint/powder system. |
| 6. | Prior to painting, check to be sure air pressure is below 75psi in your air line to prevent damage to the insert. |
| 7. | Decrease paint/powder dosage when necessary. |
| 8. | Paint as usual. |
| * | Tip 💡: Remember to adjust paint/powder dosage once inserted and stand back from the substrate to get the full advantage of the FARROW FLOW insert. |



FARROW FLOW, INC.

Downingtown, PA 19335

info@farrowflow.com

www.farrowflow.com

484-359-1900

Specifications

| | |
|---|--|
| Length | 10" / 254mm |
| Width | .75" / 19.05mm |
| Material | Thermoplastic Polyurethane (BPA and Styrene free) |
| Part# | FF-1787-BC |
| Weight | 16oz / 1lb |
| Straight Connector: 10MM X 8MM Push to Connect | Nylon |



Safety Warning

- **Inserts are delivered factory assembled and ready for connection with a 6mm connector.**
- *Prior to installation, check air pressure is below 75psi in your air line to prevent damage to the insert assembly.*
- *Do not exceed maximum 75 psi while Farrow Flow is inserted inline.*
- *Shut down air supply prior to any adjustment, connection installation or removal of the Farrow Flow insert assembly.*
- **TO CLEAN THE FARROW FLOW INSERT, USE MILD SOAP AND WATER ONLY!**
- *DO NOT use cleansing agents such as acetone, benzene, carbon tetrachloride, gasoline, toluene etc. which are damaging to the plastic.*
- *Do not use wrenches or pipe grips on the Farrow Flow as this could cause damage to the insert assembly.*